





 <p>17 55 約2.5 紙ジャクリ 組子(棧) ≒14 55 アジャスター</p>	<p>荒益子障子(1)</p> 	<p>荒益子障子(2)</p> 	<p>益子障子</p> 
 <p>≒14 木製引手 ≒8 30</p>	<p>豎繁障子</p> 	<p>吹き寄せ障子</p>  <p>70</p>	<p>ムカデ障子</p> 